

# Beyond Green Cleaning

8009-005

## BioRem-2000 Solvent Safety Spill Kit™

### Description

- **Microbe-powered absorbent.**
- **Chemically selective to hydrocarbons.**
- **Removes sheen.**
- **Repels water.**
- **Transforms pollutant into stable solid.**
- **Fully recyclable.**
- **Non-leaching.**
- **Incinerates to minimum residual ash content.**

### Safety Spill Kit



### Technical Information

Usage	Dilution Ratio	RTU
Physical Properties	Appearance	Powder
	Color	White
	Fragrance	None
	pH	7
	Shelf Life	Minimum 1 Year
Packaging	8009-005	(1) 5 gal./18.9 L

### Advantages

BioRem-2000 Absorbent™ is an all-natural material which is made of protein and carbohydrate matrix used to absorb oil-based spills efficiently. Traditional absorbents often experience a “dripping wet paper towel effect” in which the technology, when saturated, leaks oils and other pollutants back into the water. On the other hand, BioRem-2000 Absorbent™ fully encapsulates recovered oil resulting in a substantially more effective response that prevents absorbed oil from leaching. It is also capable of removing low levels of oil from water, thereby successfully removing sheen. In addition, the BioRem-2000 Absorbent™ remains buoyant in calm or agitated water, permitting it to remain in place until fully saturated and resulting in no wasted product. Once oil is absorbed, the BioRem-2000 Absorbent™ transforms the pollutants into a stable solid for easy recycling, providing a closed-loop solution to water pollution.

### Application

Identify and obtain your personal protective equipment. Wear and use all protective equipment contained in the kit at all times before, during and after spill clean-up. Apply BioRem-2000™ Super Absorber to the spill around its perimeter to dike the liquid, being careful not to inhale the vapors and avoid splashing the spilled material. Spray BioRem-2000™ Surface Cleaner onto the solvent spill covering the entire spill area to eliminate ignition hazards and to neutralize the solvent. Cover the entire spill area with the BioRem-2000™ Super Absorber to absorb any remaining material. Place waste in disposal bags provided and properly dispose of waste according to Regulations in your area.

Clift Industries, Inc.

PO Box 67153 • Charlotte, NC 28226

800-996-9901 • 704-752-0031 • Fax: 704-544-2532

www.cliftindustries.com

